



ADEN M&E PTE LTD

(Co. Reg. No.: 202010794G | GST. Reg. No.: 202010794G)

1 Soon Lee Street, #03-01 Pioneer Centre, Singapore – 627605

Tel: 6992 2743, Fax: 6721 9243, H/P: 8321 4226

Email: justin@adenme.com

Website: www.adenme.com

“ Promastop ” FR MORTAR

METHOD OF STATEMENT	SAFE WORK PROCEDURE
<ol style="list-style-type: none"> 1. Ensure all service penetrations are completed and installed to manufacturer's recommendation; 2. Remove loose debris from all openings; 3. Friction fit 50mm, 120kgs/m³ mineral wool as a formwork within the thickness of the wall/floor, recessed sufficiently to allow installation of the correct FR Mortar thickness (40mm thick for up to 2-hour and 60mm for up to 4-Hour Rating); 4. The FR Mortar should be thoroughly mixed with water based on the ration of 2 parts FR Mortar : 1 part Water to achieve the required consistency; 5. The FR Mortar shall be Poured or Toweled onto the opening and build up to the required thickness (40mm/60mm), usually flushed with the slab surface; 6. The FR Mortar should then be smoothed to a neat finish before it begins to cure; 7. The applicator shall attached a Fire Stopping Sign in close proximity to the seal, indicating Date of installation & Contact No. 	<ol style="list-style-type: none"> 1. For areas unable to inspect visually, use gloves before checking the area; 2. Use gloves and / or broom to clear loose debris; 3. Wear glove on the hand holding the mineral wool while cutting mineral wool to the required size. Wear safety harness & anchors if working at height. When one worker climbs up and A-ladder, another worker must be below holding the A-ladder firmly; 4. Not applicable. 5. Wear safety harness & anchors if working at height. When one worker climbs up and A-ladder, another worker must be below holding the A-ladder firmly; 6. Not applicable. 7. Not applicable.



* Fire Stop * DR/WR/Hydrant Fire rated

* Fire Rated Duct & General Building Service

* Fire Collor * MCT * Stainless Steel/Acrylic Box-Up